



PRESTO CHANGO with Banana Jacks

User Manual v1 8/26/2018



The Presto Chango is a passive adapter box that provides the use of up to 4 standard expression pedals, like the Moog EP2 and EP3, with banana jack format modular synths. The Presto Chango has been tested to work with Moog EP2 and Moog EP3 Pedals, which have TRS audio connectors. Others with a TRS connector may work, but have not been tested. Expression pedals with only a TS style connector will not work with the Presto Chango.

For each of the 4 independent MAGIC channels there are 3 connections: IN, PEDAL, OUT. Connect the CV source to 'IN'. Connect the expression pedal to 'PEDAL'. Connect the CV 'OUT' to the destination. The black banana jack on the Presto Chango is the common ground to all 4 channels. Connect the Presto Chango GROUND jack to the ground banana jack on your synth.

Expression pedals are voltage dividers, so they range from about 100% of the CV source voltage to having no affect. Some expression pedals have dials/switches you may need to adjust to get ideal performance voltage range. This is the case even when you are able to directly connect the pedal to the synth.

COMMON SENSE DISCLAIMERS: Only connect compatible equipment in a manner that you are sure the destination can handle the source voltage(s). This device does not process, nor change the voltages, nor provide protection in any way. For instance, if you provide a negative voltage to a device that cannot handle it or a voltage beyond what the destination device is compatible with, you may damage the equipment just as you would if you connected it directly.

If you have any questions about this device, please visit: www.tricksmagicshop.com