




## SLEIGHT OF HAND with Eurorack Jacks

User Manual v1 6/23/2018



The Sleight of Hand with Eurorack (3.5mm Mono) Jacks is a passive, three-channel, CV (control voltage) signal footswitch for modular/semi-modular synthesizers. Upon the click of the footswitch, up to three CV source signals switch between their respective A and B inputs to their correlating outputs. All three channels switch simultaneously. Clearly, you can just use a single channel as well by simply using, for example, only the Channel 1 CV A & B Inputs and the Channel 1 CV Output. While the jacks certainly can switch between audio signals too, it's possible the a 'pop' may be audible upon clicking the footswitch if using with audio signals.

Alternately, per channel, you can reverse the CV Inputs and CV Outputs to alternate between two destinations, per channel, upon clicking the footswitch.

**COMMON SENSE DISCLAIMERS:** Only connect compatible equipment to the Sleight of Hand in a manner that you are sure the destination can handle the source voltage(s). The Sleight of Hand does not process, nor change the voltages, nor provide protection in any way. For instance, if you provide a negative voltage to a device that cannot handle it or a voltage beyond what the destination device is compatible with, you may damage the equipment just as you would if you connected it directly. Don't try to operate underwater. Don't use your tongue to check signals. Don't use while driving. We are not responsible for any damage to equipment or body parts that occur from misuse or lack of common sense. Have fun.

If you have any questions about this device, please visit: [www.tricksmagicshop.com](http://www.tricksmagicshop.com)